

SOLIS B-GREEN

PROTECTS YOUR EYES AND THE ENVIRONMENT

The first environmental friendly safety glasses, SOLIS B-GREEN are made from renewable plant materials. «OK biobased» certified by the Belgian laboratory Vincotte, the frame contains 40% biocarbon. Environmental-friendly material manufacturing and recycling produces less greenhouse gas.



SOLIBPSI

28 g

SUPPLIED WITH

Recycled cardboard box
and instructions



- + SCREW-LESS**
- + ANTI-SCRATCH, ANTI-FOG COATING**
- + 18 G LIGHTWEIGHT FRAME**
- + FRAME MADE FROM RENEWABLE, PLANT MATERIAL**

bollé
SAFETY

SOLIS B-GREEN

PROTECTS YOUR EYES AND THE ENVIRONMENT

MODEL	VERSIONS	REFERENCES	LENS MARKING	FRAME MARKING	COATINGS
SOLIS B-GREEN	 Clear	SOLIBPSI	2C-1,2  1 F 	 EN166 F 	Anti-scratch/anti-fog

LENS MARKING



Optical class symbols:

1. Continuous work

Mechanical strength symbols:

- F.** Low energy impact, resists a 6 mm, 0.86 g ball at 45 m/s
Maximum protection for glasses.

Others symbols:

 European standard  Manufacturer name

FRAME MARKING

EN 166: guaranteed minimum resistance of the protective eyewear against everyday risks including dropping the protective eyewear onto the ground, ageing by light exposure, exposure to heat or corrosion etc.

- F.** Low energy impact, resists a 6 mm, 0.86 g ball at 45 m/s
Maximum protection for glasses.

 European standard  Manufacturer name

Bollé Safety product approval certificates to CE standards will be sent on request.

CLEANING AND STORAGE

CLEANING: The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

MAINTENANCE: Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

STORAGE: All products must be stored in a dry and clean environment.

PACKAGING AND EAN13 CODE	
	SOLIBPSI
Individual plastic bag	3660740003586
160 safety spectacles per outer pack	3660740203580

CHARACTERISTICS	
LENSES	PC - 2,0 mm - Curve 8
FRAME	Ecovio®
TEMPLES	Ecovio®
STRAP	Non applicable
FOAM	Non applicable
SPARE LENSES	No



01/10/2013

Europe Bollé Safety
95 rue Louis Guérin
69100 Villeurbanne - France
Tél. : 00 33 (0) 4 78 85 23 64
Fax : 00 33 (0) 4 78 85 28 56
contact@bolle-safety.com

bolle-safety.com

U.K. Bollé Safety
Unit C83 - Barwell Business Park Leatherhead Road - Chessington
Surrey - KT9 2NY
Tél. : 00 44 (0)208 391 4700
Fax : 00 44 (0)208 391 4733
e-mail : sales@bolle-safety.co.uk

bolle
SAFETY